

INSTALLATION INSTRUCTIONS FOR REMOTE VIEW SOFTWARE

Down load and unzip software
Connect phone to computer
Open Active Sync software
Hit setup in unzipped software folder



setup.exe


Follow on screen prompts
Phone will show download



ecamit Icon will be placed in your phones program folder

Finish

To add your cameras to view:

Open your remote view software :  ecamit

Hit **add**

Site name: enter a name for your camera

Camera ID: enter your camera number found on the back of your camera (ie; b511xxxx)

Hit **ok**

To view cameras

Tap to highlight camera

Tap search

Tap camera to view